

DACIA LOGAN (Renault) 4p
 DACIA SANDERO (Renault)

MOCSKT 050



MOCSRR0AL008 cm 110

MOCSRR0AC012 cm 110

4 - L 1122		8 - RCVM6X16Q		1 - RCBR5	
8 - RCVM6X9Q		8 - RCRD6Q		1 - RCBR4	
		4 - RC20200026			

I - montare gli attacchi, non bloccare le viti
 GB - fit the clamps, don't tighten the screws
 E - ajustar las pletinas, no apretar

