


Installation Manual

BMW 3 SERIES 4DR
BMW-3SER-4-A



COMPONENTS INCLUDED



CL-M01 x 4



CL-P02 x 2



CL-W01 x 1

Installation

BMW 3 SERIES 4DR

BMW-3SER-4-A



Installation

BMW 3 SERIES 4DR
BMW-3SER-4-A

