










KIA Picanto 2017



MOCSKT 0355

MOCSRROAC0010 cm 110


MOCSRROAL0006 cm 110




<p>1 - L1169/18 ant. sx</p> 	<p>1 - L1169/16 post. dx</p> 	<p>4 - L1204/4</p> 	<p>4 - RC20200026</p> 
<p>1 - L1169/28 ant. dx</p> 	<p>1 - L1169/26 post. sx</p> 	<p>4 - L1058/8</p> 	<p>8 - RCVM6X9Q</p> 
			<p>1 - RCBR5</p> 



MOCSRROAC0010 cm 110
MOCSRROAL0006 cm 110






anteriore, avant, front,
vorne, delantera




posteriore, arriere,
rear, hinten, trasera

MOCSKT 0355




L1169/18
L1169/28
+
L1204/4

cm 20



cm 50



L1169/16
L1169/26
+
L1204/4



L1169/28



L1169/18

anteriore, avant, front,
vorne, delantera






L1169/26



L1169/16

posteriore, arriere, rear,
hinten, trasera



I - Per stringere, usare la chiave come indicato nel disegno. (Non si assumono responsabilità per danni causati dall'impiego di chiavi diverse da quella in dotazione al prodotto).
F - Pour serrer, utiliser la clé comme indique ci dessous.

GB - To tighten please use the wrench as per the drawing.
D - Zum Anziehen benutzen Sie bitte den Inbusschlüssel, nur wie auf dem Bild dargestellt.
E - Para el correcto ajuste, utilizar la llave fija tal y como se indica en la imagen

