


EN Fitting Instructions for Basic Carrier







## MAX kgs (lbs)

☐ W/P WHD

### Volkswagen

Transporter T5 LWB (4 Bar), 4dr Van 03-15	AU	75 kgs (165 lbs)	75 kgs (165 lbs)
Transporter T5 LWB (4 Bar), 4dr Van 03-15	NZ	75 kgs (165 lbs)	75 kgs (165 lbs)
Transporter T5 LWB (4 Bar), 4dr Van 03-15	ZA	75 kgs (165 lbs)	75 kgs (165 lbs)
Transporter T5, 4dr Ute 03-Dec 15	NZ	75 kgs (165 lbs)	75 kgs (165 lbs)
Transporter T5, 4dr Ute 03-Dec 15	AU	75 kgs (165 lbs)	75 kgs (165 lbs)
Transporter T5, 4dr Ute 03-Dec 15	ZA	75 kgs (165 lbs)	75 kgs (165 lbs)
Transporter T6 LWB, 4dr Van 15-+	ZA	75 kgs (165 lbs)	75 kgs (165 lbs)
Transporter T6 LWB, 4dr Van 15-+	CN	75 kgs (165 lbs)	75 kgs (165 lbs)
Transporter T6 LWB, 4dr Van Dec 15-+	NZ	75 kgs (165 lbs)	75 kgs (165 lbs)
Transporter T6 LWB, 4dr Van Dec 15-+	AU	75 kgs (165 lbs)	75 kgs (165 lbs)



	A	B	C	D	X			
					1	2	3	4
Transporter T5 LWB (4 Bar), 4dr Van 03-15 (AU)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	1300mm 51 1/8ths"	2320mm 91 3/8ths"	1100mm 43 5/16ths"	1100mm 43 5/16ths"	1100mm 43 5/16ths"	1100mm 43 5/16ths"
Transporter T5 LWB (4 Bar), 4dr Van 03-15 (NZ)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	1300mm 51 1/8ths"	2320mm 91 3/8ths"	1100mm 43 5/16ths"	1100mm 43 5/16ths"	1100mm 43 5/16ths"	1100mm 43 5/16ths"
Transporter T5 LWB (4 Bar), 4dr Van 03-15 (ZA)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	1300mm 51 1/8ths"	2320mm 91 3/8ths"	1100mm 43 5/16ths"	1100mm 43 5/16ths"	1100mm 43 5/16ths"	1100mm 43 5/16ths"
Transporter T5, 4dr Ute 03-Dec 15 (NZ)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	- -	- -	1095mm 43 1/8ths"	1095mm 43 1/8ths"	- -	- -
Transporter T5, 4dr Ute 03-Dec 15 (AU)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	- -	- -	1095mm 43 1/8ths"	1095mm 43 1/8ths"	- -	- -
Transporter T5, 4dr Ute 03-Dec 15 (ZA)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	- -	- -	1095mm 43 1/8ths"	1095mm 43 1/8ths"	- -	- -
Transporter T6 LWB, 4dr Van 15-+ (ZA)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	1300mm 51 1/8ths"	2320mm 91 3/8ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"
Transporter T6 LWB, 4dr Van 15-+ (CN)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	1300mm 51 1/8ths"	2320mm 91 3/8ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"
Transporter T6 LWB, 4dr Van Dec 15-+ (NZ)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	1300mm 51 1/8ths"	2320mm 91 3/8ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"
Transporter T6 LWB, 4dr Van Dec 15-+ (AU)	-140mm -5 -1/2ths"	500mm 19 11/16ths"	1300mm 51 1/8ths"	2320mm 91 3/8ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"	1085mm 42 11/16ths"


## Items you will require:

- 12mm Socket
- 13mm Socket

## First Time Installation



- Remove parts from inside the package and check. Contact your dealer if any parts are missing or damaged.



- This kit fits type A, B, C and D.
- These instructions show type A crossbar fitted. They also apply to type B, C and D.

- Use keys to remove covers.




- Use hex screwdriver to reverse adjusting screw 10 turns.



- Press adjusting screw and pull crossbar legs out. Refer to the crossbar instructions for crossbar adjustment method.
- Ensure each end of the crossbar is adjusted equally.






- Set bars to length (revert to rear of these instructions).
- Please check the front of this manual for information relating specifically to your vehicle.



- Tighten adjusting screw to 2 Nm (1.5 ft lb) hand tight.



- Remove plastic clamp block by gripping bar leg with fingers and push firmly with thumbs until clamp block drops out behind leg.



- Remove both pins from each leg. Use tapered end of spanner located inside left hand cover to assist.



- Detach foot from leg. Store loose parts in a safe place.
- Repeat for all legs.



- Assemble foot from kit into leg.

- Insert pins through foot into leg.




- Select plastic internal block (from fitting kit) and insert into foot.
- Repeat for all legs.



- Refer to the top side of the pad for the part number.







- Letters refer to the pad part numbers and position.
- Pad Part Number:  
A = 244A  
B = 245A




- Fit rubber pads (supplied with fitting kit) to foot. Pad may vary in shape to that shown.

## Fitment



- Open or remove fixed-point covers.



- Select grubscrews and screw into the vehicle's fixed points.
- Do not over tighten.
- Repeat for all positions.



- Place rubber seal over bolt thread as shown.
- Place second flat washer over rubber seal.
- Place M6 flange nut over grubscrew and tighten down.




- Place crossbar foot over grubscrews.
- Sit rubber foot pads down into the roof recess channel.



- Tighten the plastic knob. The side with the nut showing should be facing up.



- In the fully tightened position, the knobs should be parallel with the vehicle.
- Repeat for all positions.



- Check crossbar is securely attached to the vehicle.
- Use keys to fit and lock covers

**CAUTION: Recheck all fasteners immediately after a load is applied to the crossbars.  
Regularly check screws are tight.**

---

## Maintenance

- Clean the car roof and surfaces of the product that will be in contact with the car roof.
- Follow the fitting instructions for fitting the product to your vehicle. Make sure all steps are carried out in order.
- Set crossbars a minimum distance of 700mm (27 1/2") apart where no other distance is specified in the fitting instructions. This is especially important when carrying long loads.
- Check unit is securely attached whenever you refit it to the vehicle. If the unit feels loose, refer to the fitting instructions and readjust.
- Some glass/panoramic roofs and radio antennae may not be able to be used when the product is fitted.
- Do not modify this product.
- Refer to the maximum permitted load capacity specified in the fitting instructions. Do not exceed the vehicle manufacturers roof load rating if it is lower than the maximum load capacity specified in the fitting instructions.
- Loads should not overhang the sides of the product and be evenly distributed with the lowest possible centre of gravity.
- Long loads should be secured with non-elastic straps to the front and rear of the vehicle.
- Objects with pointed ends (e.g. ski poles) should be carried with the pointed ends to the rear of the vehicle.
- Remove all loose or removable objects from the load prior to loading.
- Make sure all loads are securely fastened with non-elastic straps. Check regularly during longer journeys.
- A loaded roof rack system can alter the performance of your vehicle. Be especially aware of the effects of side winds, changing of direction, and braking performance. Avoid rapid acceleration and deceleration. Drive carefully.
- Note that the total height of the vehicle increases when upright loads are carried.
- Products should be locked during transport if they have locks fitted.

- Check and replace worn out or defective parts.
  - Keep the product clean and maintained.
  - Never drive into a car wash with the roof rack system fitted.
  - Lubricate locks and adjusting screws at regular intervals.
  - Remove the products from the vehicle when not in use. Make sure all loose parts are stored safely.
- 

- Yakima Europe Coöperatief U.A.  
Archimedesbaan 25  
3439 ME Nieuwegein  
The Netherlands

+31 2080 81425

[www.whispbar.eu](http://www.whispbar.eu)  
[www.whispbar.co.uk](http://www.whispbar.co.uk)

---

- Yakima Products, Inc.  
15025 SW Koll Pkwy.  
Beaverton, OR 97006-6056  
USA

[www.whispbar.com](http://www.whispbar.com)  
[www.whispbar.ca](http://www.whispbar.ca)

---